

BL300 Manual



Switching on and off

Remote control Blinc™ BL300 uses batteries 27A and operates in power saving mode without turning off the device.

The battery lasts a year with a normal daily use.

BL100 conjunction with the Remote Control

Turn on the **BL100i**, press and hold the "Volume Down" for 6 seconds until the blue LED stops flashing.

Press and hold any two buttons simultaneously on the remote control BL300 until the blue light on BL100i goes off, which means that the matching process was successful.

Call via remote control

- Double click on the green button "Call" in standby mode to start a call.
- Double click on the gray button "Play / Pause" when BL100i is on standby will call the last number.
- When you have an incoming call, press the green "Call" to answer.
- To end a call, press the green button "Call".
- To reject a call when the phone rings, double-click on the green button "Call"

Music control

- Press the gray "Play / pause" to start the music from your phone, if you are not listening to any songs.
- Press the gray "Play / pause" to pause the song.
- Press the "Next song / volume increases" to go to the next song.
- Hold "Next song / increase volume" to increase the volume.
- Press the "Previous Song / decrease volume" to return to the previous song.
- Press and hold the "Previous Song / decrease volume" to decrease the volume.

Warning: high volume can cause hearing damage.

Intercom call

When activated the intercom function on BL100i you can start a conversation by pressing the intercom button green

To end an intercom conversation, press the green "Call" again.